



## How to change the combination?

\*The initial combination is 0000.

\*Press and hold the red button, then set the desired new combination.

\*Remember the new combination!

\*Release the red button, press and hold the silver button, pull down the side plate, and the combination will be changed successfully.



## How to unlock?


Set the correct combination, press and hold the silver button and at the same time pull down the side plate.

## How to lock?

\*Press and hold the silver button, insert the side plate into the lock.  
\*Pull the side plate to ensure the lock is locked.

## Installation Method:

Attach the folding lock to the bike beam using the mounting material in the kit as shown.



**Kwikset**


## ¿Cómo cambiar la combinación?

\*La combinación inicial es 0000.

\*Mantén presionado el botón rojo, luego configura la nueva combinación deseada.

\*¡Recuerda la nueva combinación!

\*Suelta el botón rojo, mantén presionado el botón plateado, baja la placa lateral y la combinación se cambiará correctamente.



## ¿Cómo desbloquear?

Configura la combinación correcta, mantén presionado el botón plateado y al mismo tiempo baja la placa lateral.


## ¿Cómo bloquear?

\*Mantén presionado el botón plateado, inserta la placa lateral en la cerradura.

\*Tira de la placa lateral para asegurarte de que la cerradura está bloqueada.

## Método de Instalación:

Fija el candado plegable al tubo del cuadro de la bicicleta usando el material de montaje incluido en el kit, como se muestra.



**Kwikset**